


LABEL MOVER

Moves the material a few millimeters and improves 100% the waste removal process

The Label Mover is designed to allow labels to be **moved a few millimeters from their initial position** to a new position on the support material. It can be used for **two reasons**:

One product, double duty

- Reduces the adhesive tag to remove the waste matrix easier.
- Moves the label inside the liner to avoid problems during label dispensing.



LABEL MOVER



Total integration

It is installed in the die-cutting station itself, without having to make any changes.



Reduce mistakes

Avoid problems with kiss cutting during the die cutting process and improve the label dispensing.



Higher performance

Get a faster performance with the waste matrix removal and prevent that the back material gets broken.



Easy operation

We work to make all our equipment intuitive and easy to use by any operator.

The most renewed Label Mover Makes work easier and optimize time

- The position adapter allows to **adjust the position of the label on the paper.**
- The **support cylinders** ensure that **the paper follows the correct path** inside the machine.
- Once the material has been moved, the re-lamination cylinder re-laminates it **to prevent the movement of the label.**